


P18-200



01	ES-82	EXHAUST TURNER	25	CA-12	END CAP	49	P-95	WEAR PLATE
02	M5x20	HD. SCREW	26	SW-08	Return Seal	50	SM-118	PIN
03	CA-52	BODY CAP	27	M5x20	HD. SCREW	51	SP-92	SPRING
04	ES-26	EXHAUST	28	OR-103	O-RING	52	FC-134	STOP PIN
05	OR-78	BODY CAP O-RING	29	SM-74	STEP PIN	53	SM-32	MAGAZINE PIN
06	WS-71	GAKET	30	SM-65	E.RING	54	M5x18	HD. SCREW
07	SP-44	SPRING	31	DL-09	LATCH	55	WS-01	WASHER
08	OR-03	POPPET O-RING	32	FP-38	FRONT PLATE	56	HR-30	HANGER
09	PV-14	POPPET VALVE	33	ES-22	SAFETY GUIDE	57	FC-135	STOPPER
10	OR-84	POPPET O-RING	34	SP-43	SAFETY SPRING	58	WS-05	WASHER
11	OR-85	POPPET O-RING	35	ST-109	SAFETY	59	M4*12	HD. SCREW
12	WS-47	GUIDE SPACER	36	ES-83	NO-MAR TIP	60	M5*7	HD. SCREW
13	CY-56	CYLINDER	37	SM-43	TRIGGER PIN	61	MZ-44	MAGAZINE
14	OR-06	CYLINDER O-RING	38	SM-11	PIN	62	FD-84	FEEDER
15	OR-65	CYLINDER O-RING	39	M5	NUT	63	ES-20	SPRING STEM
16	CA-57	LINDER	40	ES-27	VALVE SEAL	64	SP-40	FEEDER SPRING
17	OR-139	LINDER O-RING	41	SP-21	SPRING	65	MC-34	MAGAZINE COVER
18	OR-07	PISTON O-RING	42	OR-77	VALVE STEM O-RING	66	SM-07	SPRING PIN
19	PS-46	PISTON & DRIVER ASSEMBLY	43	VS-34	TRIGGER VALVE STEM	67	FC-32	TAIL COVER
20	BP-01	BUMPER	44	VS-35	TRIGGER VALVE HOUSING	68	WS-02	WASHER
21	SW-01	SEAL WASHER	45	OR-11	O-RING	69	M4*8	HD. SCREW
22	OR-10	TRIGGER PIN O-RING	46	SP-39	SPRING	70		
23	BD-68	BODY	47	TG-57	TRIGGER ASSEMBLY	71		
24	OR-87	CAP O-RING	48	M4*12	HD. SCREW	72		